


# Installing the InstantTrust Marine

You can install the InstantTrust Marine in 3 steps

Connecting the water supply

Connecting the electricity

Mounting the faucet filter or the in line filter



## Connecting the water supply

Be sure that the water supply is turned off!

Screw the InstantTrust Marine to a wall or to the ground. You can also mount it to a custom made plank.

Cut the water hose and place the InstantTrust UV unit between it.

Fasten the hose to the InstantTrust UV unit with the hose clamps.

You cannot put force at the 2 hose connectors of the InstantTrust UV unit, it could break!

## Connecting the electricity

There are 2 ways to connect the electricity of the InstantTrust Marine:

Via the pump switch

With a Flow switch

## Connecting the power.



### ATTENTION!

Before you begin the following steps you must shut off the power supply to prevent a possible short circuit. Install the Instant Trust Marine on a plastic or waterproof wooden backplate.

**Attention:** Make sure the housing does not make contact with metal parts of the boat.  
**Note:** For the battery connection to the water pump use wire with conductors having a diameter of at least 0.5 mm up to 2 metres in length. Ensure that the wires to the battery terminals on the water pump are securely connected.

### 1. Electrical connection of the InstantTrust Marine

See: figure A or figure B for the schematic overview.

The InstantTrust Marine is protected against incorrect connection of the voltage and the pump switch.




Figure A

With pump switch




Figure B

With flowswitch

## Mounting the faucet filter or the in line filter

Click the following links for the instructions of mounting the faucet or in line filter

Mounting the faucet filter

Mounting the in line filter


# InstantTrust Marine 房车净水器安装

分3步

接水

接电

安装水龙头过滤器或者在线过滤器



## 接水

确保供水已关闭！

将 InstantTrust Marine 拧到墙上或地面上。您也可以将其安装到定制的木板上。

剪断水管并将 InstantTrust 紫外线装置放在其间（针对加装，并不是初装）。

用软管夹将软管固定到 InstantTrust UV 装置上。

您不能对 InstantTrust UV 装置的 2 个软管接头过分施力，以免断裂！

## 接电

两种接法:

- 1) 通过水泵开关
- 2) 通过流量阀开关

## Connecting the power.



## ATTENTION!


Before you begin the following steps you must shut off the power supply to prevent a possible short circuit. Install the Instant Trust Marine on a plastic or waterproof wooden backplate.

**Attention:** Make sure the housing does not make contact with metal parts of the boat.  
**Note:** For the battery connection to the water pump use wire with conductors having a diameter of at least 0.5 mm up to 2 metres in length. Ensure that the wires to the battery terminals on the water pump are securely connected.

## 1. Electrical connection of the InstantTrust Marine


See: figure A or figure B for the schematic overview.

The InstantTrust Marine is protected against incorrect connection of the voltage and the pump switch.



### Figure A

With pump switch



### Figure B

### With flowswitch

## 安装水龙头过滤器或在线过滤器

见相关附件

## 水龙头过滤器安装 在线过滤器安装